IMPORTANT SAFETY INSTRUCTIONS READ AND FOLLOW ALL SAFETY INSTRUCTIONS

CAUTION: To reduce the risk of fire, electric shock, or injury to persons:

a) Use only insulated staples or plastic ties to secure cords;

b) Route and secure cords so that they will not be pinched or damaged when the cabinet is pushed to the wall;

c) Position the portable cabinet light with respect to the cabinet so the lamp replacement markings are able to be read during relamping;

d) Not intended for recessed installation in ceilings, or soffits; and

e) The National Electrical Code (NEC) does not permit cords to be concealed where damage to insulation may go unnoticed. To prevent fire danger, do not run cord behind walls, ceilings, soffits, or cabinets where it may be inaccessible for examination. Cords should be visually examined periodically and immediately replaced when any damage is noted."

CAUTION: To prevent the risk of fire, do not install in a compartment smaller than 300mm by 300mm by 400mm.

Suitable for dry location indoor use only. It is equipped with USB wire.

SAVE THESE INSTRUCTIONS

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

The Responsible (located within the United States) party information:
Company Name: Vanco International
Address: Batavia, IL, 60510 USA
Telephone Number: (800) 525-7025
Email: info@justhookitupcables.com

The name and model number of the product:

Model Number	Model Name
190720-03	LIGHT BAR RGB
190715-00	RF 2.4GHz Remote

GET INSPIRED

Subscribe to our Pinterest boards to learn all the cool things you can do with Monster IlluminEssence.

For Ideas and Inspiration:
www.pinterest.com/monsterilluminessence

GET HELP

For Instructional Videos:
www.youtube.com/monsterilluminessence

FOR TECHNICAL SUPPORT GO TO:
https://www.justhookitupcables.com/justhookitup/support/
OR CALL: 1 (800) 525-7025

rm 880187-00

MONSTER ILLUMINESSENCE | JUST COLOR IT UP

LIVE IN COLOR

INSTALL LED LIGHT BARS

TWO OPTIONS TO INSTALL

1. Install with Velcro（2pcs Hook Side & 2pcs Loop Side）

Peel off backing from adhesive

Plug the USB cable into (TV or PC) USB port or a 5V USB power supply (not included).



a: 6.15 inch between 2 velcro
b: ≥0.7 inch from velcro to the wall

2. Install with base support



USB WALL ADAPTERS NOT INCLUDED.

USING YOUR REMOTE



Battery Warning Statement
Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

AAA BATTERIES REQUIRED (NOT INCLUDED)

COLOR RING
Choose the color of your lights.

BRIGHTNESS
Dim from 10% - 100%.

PRESET LIGHT PROGRAMS
Eight different auto programs for parties, lounging, and special occasions.

CLUB 1
Magenta | Purple | Blue | Red

CLUB 2
Cyan | Turquoise | Green | Red | Magenta | Purple | Blue | Orange

LOUNGE
Magenta → Purple → Blue → Red

BEACH
Cyan → Turquoise → Green

SUNSET
Yellow → Sunset → Orange

CHRISTMAS
Green → Red

INDEPENDENCE
Red → Blue

HALLOWEEN
Orange → Purple

SPEED
Adjust program speeds faster for parties and slower for an elegant change of atmosphere.

PAIRING

By default, all Monster IlluminEssence LED light bars will be paired out of the box with the included remote control.

TO PAIR
To pair LED light bars to another remote, simply unplug and replug back in the LED light bars to power and WITHIN FIVE SECONDS of plugging back into power, press and hold the "Speed+" until the lights blink three times.



TO UNPAIR

Repeat above but instead of "Speed+" press "Speed-".

EXPAND

EXPAND LIGHTS AND ROOMS
You can pair up to four remotes with up to 30 Monster IlluminEssence LED strips, LED light bulbs or LED light bars.

You can have multiple remotes control the same set of lights.



You can also have different sets of lights paired to different remotes to control rooms independently.