

MONSTER®

M100

TWS PORTABLE

LED WIRELESS SPEAKER

TWS PORTATIL ALTA VOZ LED INALÁMBRICO



Model: 2MNSK2171B0A4

Power/Play/Pause key:

1. Hold the power button to start the speaker; you will hear a prompt tone, and the blue light will flash.
2. Press and hold the power button to turn off the speaker; the light will shut down.
3. The blue light flashes slowly when playing music and stays solid when paused.

Telephone answering:

After successfully pairing the Bluetooth speaker, click the power key to answer phone calls, another click hangs up, and a Hold refuses the call.

TWS mode:

When two speakers of the same model are not connected to a phone, press the power key of one speaker to pair them, entering TWS mode. Press again to unpair them.

Light Button:

1. Double click to toggle light on/off.
2. Press to switch the light modes
3. Hold to switch between TF card and Bluetooth mode.

Volume up key:

Press for volume up; Hold for the next song.

Volume reduction key:

Press for volume down; Hold for the previous song.

Mode switching:

Hold the light key to switch between TF card and Bluetooth mode.

Operating Instructions:**Bluetooth Pairing:**

1. Hold the power button to turn on the speaker. There will be a voice prompt tone, and the speaker enters Bluetooth search mode with the blue light flashing rapidly.
2. Turn on your phone's Bluetooth or other Bluetooth device to search for "Bluetooth Name: MONSTER M100," and click to pair. The LED light will flash slowly after a successful connection.

Music Playback:

1. Click the power key to play or pause music; double click to unpair from phones.
2. Use the volume keys to adjust the volume and Hold to skip to the previous or next song.

TF Card:

When inserting a TF card into the card slot, a voice prompt tone will occur, and the speaker will automatically read audio files and play music from the TF card. You can control music playback using the speaker buttons.

TWS Pairing Mode:

1. When two speakers are not connected to a phone, press the pause/playback button of one speaker once to enter pairing mode. The main speaker's light flashes slowly, and the secondary light is always on.
2. After TWS pairing, but before connecting your phone, you can click the power key of the main speaker once to exit the pairing mode or the pause/playback button to unpair.

Charging:

Charge using the provided charging cable with a voltage of DC5V. The red light remains solid while charging and turns off when fully charged.

Mode Switch Key:

1. Double-click the LED light key to toggle the light effects on or off, Press to switch between light effects, and press and hold the light key to switch between TF/Bluetooth play modes.



Automatic Shutdown:

1. The speaker will automatically turn off if no Bluetooth devices are connected within 10 minutes.
2. If no music is played after the speaker is connected, it will automatically turn off in 20 minutes.

Important Safety Information:

Before using the Bluetooth speaker, please consider the following safety tips for safe and reliable use of the product:

1. Read and understand all safety guidelines.
2. Use charging equipment that can provide an output voltage of DC5V/1A to avoid damage.
3. The product has a built-in lithium battery; please turn it off when not in use.
4. Keep the product away from high-temperature heat sources, and do not expose it to high temperatures.
5. Avoid dropping, impacting, or applying heavy pressure to the product.



FCC Statement

This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty

What is covered under the 2 Year Warranty?

Monster[®] warrants that this product will be free from defects in workmanship and materials under normal use ("Limited Warranty"). In a case where the product is determined to be "defective", we will repair the product free of charge. If we cannot repair the product, we will replace it for you free of charge.

How long am I covered?

You are covered for the 2 Years from Purchase

What is not covered under the Limited Warranty?

1. Normal wear and tear of product use.
2. Misuse, lack of care, mishandling, accidental damage, abuse or other abnormal use.
3. Use of the product other than for its intended purpose.
4. Damage caused by improper or unauthorized repair or maintenance.
5. Product that has been modified or altered.
6. Any product that is not manufactured by Monster[®] (including, without limitation, any non-Monster[®] product that is used in connection with the product).



website: monsterstore.com
support: support@monsterforever.com

2 Year Limited Warranty

Package Contents: (1) Speaker, (1) USB-C™ Charging Cable,
(1) User Manual

Manufactured and distributed by Lifeworks technology Group LLC. under license. New York, NY 10018. ©2023. The M Monster logo and the M slice logo are trademarks or registered trademarks of Monster Inc. and its subsidiaries in the U.S. and other countries and are used under license. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. USB-C is a registered trademark of USB Implementers Forum. Other trademarks and trade names are those of their respective owners. MADE IN CHINA



WARNING: This product can expose you to chemicals including Lead and Lead Compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

ADVERTENCIA: Este producto puede exponerle a químicos incluyendo Lead and Lead Compounds, que es (son) conocido (s) por el Estado de California como causante (s) de cáncer y defectos de nacimiento u otros daños reproductivos. Para mayor información, visite www.P65Warnings.ca.gov.